WAFER-THIN 5000mAh UL-LISTED 20W PD POWER BANK WITH BUILT-IN CABLE

INSTRUCTION MANUAL

EPB-WT26

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.

IN THE BOX

- EPB-WT26 Wafer-Thin 5000mAh UL-Listed 20W PD Power Bank (x1)

SAFETY PRECAUTIONS

- This product is NOT a toy, keep away from children and pets.
- Only use the product according to the instructions in this manual. Never use the product for anything other than its intended purpose.
- Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the product should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose product or charging cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the product or charging cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if the product or charging cable is damaged. If the product or charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Do not over charge battery.
- This product contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this product.
- Attachments on the back of your device can impede effectiveness of the wireless charger, and lead to overheating. Remove attachments from your device before charging on this wireless charger.
- The strong magnetic fields of neodymium magnets can damage items, such as television, computers, computer monitors, credit cards, bank cards, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switched to “test mode” in the presence of a strong magnetic force, if pace-maker or other electronical body implant is in use. Keep a minimum of 3 feet distance.

EN: CAUTION: Risk of Fire and Burns, don’t open, crush, disassemble and dispose of in fire. Accessible surfaces held or touched for short periods only. Don’t heat above 113°F or incinerate. Follow manufacturer’s instructions.

FR: DANGER: Risque d’incendie et de brûlures, ne pas ouvrir, démonter, écraser ni jeter au feu. Ne pas toucher.

PRODUCT DIAGRAMS



INSTRUCTIONS

Charge the power bank fully before using for the first time.

CHARGING THE POWER BANK

- Pull out the USB-C tip of the built-in charging cable and plug into USB-C port on a computer or into a certified USB-C adapter (not included), and plug into a wall socket.
- Or plug the USB-C tip of your charging cable (not included) into the USB-C port on the power bank. Plug the other end of the cable into a USB power source, such as the USB port on a computer or into a certified USB adapter (not included), and plug into a wall socket.
- The digital display will display power level while the power bank is in charging and stop flashing when the power bank is fully charged.

  Note: *When the power bank is being charged with 18W or above power adapter, the fast-charging icon will appear in digital display.*

CHARGING ELECTRONIC DEVICES WITH THE POWER BANK

- Pulling the integrated cable out of the power bank, connect the charging cable to your device with the appropriate connector.
- Or plug the USB-C tip of your own charging cable into the USB-C port on the power bank. Plug the other end of the cable into your device with the appropriate connector.
- The power bank will begin to charge automatically.
- The digital display will show available power level of battery when charging.
- Remove the cable from your mobile device when it is fully charged.

Note: *If the charged device contains magnets, simply place the device against the magnetic surface of the power bank, the device will be perfectly attached to the power bank. But no wireless charging. The charging must go through the integrated cable or your own cable.*

TECH SPECIFICATIONS

- Battery Capacity: 5000mAh/3.85Vdc/19.25Wh
- USB-C Port & USB-C Tip Input: 5Vdc/3A, 9Vdc/2A, 12Vdc/1.5A
- USB-C Port Output:9V/2.22A, 12V/1.67A, 5V/2.4A (2330mAh)
- USB-C Cable Output: 9V/2.22A, 12V/1.67A, 5V/2.4A (2500mAh)
- Cable with 7-Pin Tip Output: 9V/2.22A, 5V/2.4A (2500mAh)
- Working Temperature: 14°F ~ 113°F (-10°C ~ 45°C)

FCC INFORMATION

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

UL CERTIFIED
SAFETY US-CA
SÛRETÉ US-CA
E550538
UL 2056 Certified

Made in China