AeroSip 21 oz Eco-Friendly Vacuum Insulated Stainless Steel Bottle w/ Built-in Fan

DBT-AP26

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.

IN THE BOX


- DBT-AP26 AeroSip 21 oz Eco-Friendly Vacuum Insulated Stainless Steel Bottle (x1)
- Detachable Fan (x1)
- Charging Cable (x1)

SAFETY PRECAUTIONS

- This device is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or charging cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or charging cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or charging cable is damaged. If device or charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

PRODUCT DIAGRAMS

1. Flip-up Straw & Dust-free Protection cover
2. Flip-up Handle
3. Vacuum Insulated Bottle
4. USB-C Charging Port
5. LED Indicator
6. [Power] Button
7. Detachable Built-in Fan



FAN INSTRUCTIONS

Be sure to fully charge the fan before using for the first time.

CHARGING THE FAN

1) Plug the provided USB-C connector of the included charging cable into to the USB-C charging port (4) on side of the fan.
2) Plug another connector into a USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
3) Fully charge the battery before first use (approx. 3 hours)
4) LED Indicator (5) status:
    a) Charging: flash red
    b) Fully charged: solid red
    c) Low battery (while in use): flash red
    d) Powered on (fan running): solid blue
    e) Disconnect the charger once fully charged to extend battery life

NOTE: *DO NOT use the fan during recharging.*

USING THE FAN

1) Press the [Power] button (6) to turn the fan ON.
2) Press the [Power] button (6) to adjust fan speed level between low, medium and high.
3) Press the [Power] button (6) again to turn the fan OFF.
4) Turn the fan OFF when it is not in use.
5) The fan head can be foldable in 90 degrees.

FAN TECH SPECIFICATIONS

Battery Capacity	1200mAh/3.7V
Charging Input	DC 5V/1A
Continuous Using Time	Up to 2 hours (High Speed) Up to 3 hours (Medium Speed) Up to 4 hours (Low Speed)
Charging Time	3 hours

FCC INFORMATION

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user’ s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in China

Congratulations on your new distinctive drinkware!

Here are a few helpful tips for the **Drinkware Vessel** to enhance your enjoyment.

- Remove the Detachable Fan part before washing the Bottle.
- Detachable Fan can be independently working when not attaching to the bottle.
- Wash all bottle parts in warm soapy water before using. Do not use cleansers with bleach or chlorine to clean this product.
- Suggest for cold beverage only. Drinking hot beverages with the straw is not recommended.
- This product is able to keep liquids cold for a considerable period of time.
- Do not over fill. Liquid may escape through the drinking hole when fastening the lid.
- Always ensure the lid is fastened securely before drinking.
- This product is not for use in a microwave oven and is not dishwasher safe.

  Recommended to hand wash only.

Ariel

21 oz / 621 ml

Made in China