


## The 26oz Roamer Bottle Care and Use Instructions

## **▲** CAUTION

- · DO NOT microwave or freeze.
- · DO NOT use cleaning agent containing bleach, chlorine, or abrasive chemicals.
- · DO NOT continue to use if damaged.

## **CLEANING INSTRUCTIONS**

- · Wash thoroughly before first use.
- · RINSE IMMEDIATELY AFTER EACH USE with warm water.
- · Hand Wash Only.



- · When washing by hand:
  - Hand wash bottle with warm water in a mild detergent.
    - The lid can only be rinsed.
    - Rinse thoroughly.



NOT SUITABLE FOR DISHWASHER

It is recommended to store the product with the lid removed to allow the parts to dry completely.

## US. See nayad.com for details.

©2019 OZEAN INTERNATIONAL INC. All Rights Reserved. Should you have any questions about your purchase, please contact us at nayad.com.