

## Traveler Care and Use Instructions

## **▲** CAUTION


- · DO NOT microwave or freeze.
- · DO NOT use cleaning agent containing bleach, chlorine, or abrasive chemicals.
- · DO NOT continue to use if damaged.

## **CLEANING INSTRUCTIONS**


- · Wash thoroughly before first use.
- · Rinse immediately after each use with warm water.
- Hand Wash Only.







Fill the bottle with lukewarm water and clean the inside of the bottle thoroughly.





 Screw the spout lid to open.
 Flip the cap and push it until it "clicks" to secure. Take a sip and close it tight.

- When washing by hand:
  - Hand wash bottle with warm water in a mild detergent.
  - The lid can only be rinsed.
  - Rinse thoroughly.



NOT SUITABLE FOR DISHWASHER

It is recommended to store the product with the lid removed to allow the parts to dry completely.

## US. See nayad.com for details.

©2021 OZEAN INTERNATIONAL INC. All Rights Reserved. Should you have any questions about your purchase, please contact us at nayad.com.