

PULSE ACTIVE NOISE CANCELLING HEADPHONES

INSTRUCTION MANUAL

EHE-PU25

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.


WHAT'S INCLUDED:

- EHE-PU25 Pulse Active Noise Cancelling Headphones (x1)
- Carrying Case (x1)
- Charging Cable (x1)

SAFETY PRECAUTIONS

- This device is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or charging cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or charging cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or charging cable is damaged. If device or charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

PRODUCT DIAGRAMS



INSTRUCTIONS

Be sure to fully charge the headphones before using for the first time.

CHARGE THE HEADPHONES

- Plug the small connector of the included charging cable into the USB-C charging port on the headphones.
- Plug the large connector into a USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
- The LED indicator will **illuminate RED** when charging and **turn BLUE** when fully charged.
- *The LED indicator **flash RED** every 3 seconds and you will hear a voice prompt saying "Battery Low" when the headphones need recharging.*

PAIR & CONNECT WITH A NEW DEVICE

- Press and hold the **Multi-Function button** for 3 seconds to turn on the headphones. You will hear a voice prompt saying "Power on, device pairing".

The LED indicator will **flash RED & BLUE alternatively** to indicate the headphones are in pairing mode.

- Open the Bluetooth menu on your laptop or PC and search for new devices.
- When you see “**Pulse ANC**” listed, click it to connect. You will hear a voice prompt saying “Device connected”. The LED indicator will **illuminate BLUE** when paired successfully.
- Previously paired headphones will pair automatically after they are powered on.
- Press and hold the **Multi-Function button** for 3 seconds to turn on the headphones. You will hear a voice prompt saying “Power off”.
- *The headphones will turn off automatically if you do not connect to the headphones in 5 minutes.*

PLAYING MUSIC & CALLING

• When playing music:

- Press the **Multi-Function button** to play/pause your audio.
- Press the **[+] button** to skip to next track;
- Press and hold the **[+] button** to increase volume.
- Press the **[-] button** to skip to previous track;
- Press and hold the **[-] button** to decrease volume.

• When there is an incoming call:

- Press the **Multi-Function button** once to answer an incoming call, and again to end the call.
- 2x rapid press the **Multi-Function button** to redial last dialed phone number.

- **3x rapid press** the **Multi-Function button** to activate the voice assistance of your device, Siri (iOS devices) or Google Voice Assistant (Android devices). You will hear a tone prompt to indicate that your voice assistant is activated.

ACTIVE NOISE CANCELLING MODE

- Press the **ANC button** on right side of headphones to enter Active Noise Cancelling Mode. You will hear a voice prompt saying “Noise cancelling on”.

- The Active Noise Cancelling Mode will tune out the surrounding noise and let you focus on your music, online meeting and phone conversation.
- In the active noise cancelling mode, press the **ANC button** on right side of headphones to resume regular mode. You will hear a voice prompt saying “Noise cancelling off”.

RESET THE HEADPHONES

- If you have trouble pairing your headphones, forget the pairing name “**Pulse ANC**” from the list of the connected device and turn off the Bluetooth.
- Turn off the headphones.
- Follow the instructions under “Pair & Connect with a New Device” to pair with the headphones again.

TECH SPECIFICATIONS

Rated Output Power	12mW x2
Sensitivity	110dB ± 3db (S.P.L. at 1KHz)
Impedance	24 ohm
Frequency Response	20Hz~20KHz
S/N Ratio	> 80dB
Connection Range	33 feet
Continuous Play Time	Up to 8 hours (with max volume)
Continuous Play Time	Up to 6 hours (with ANC on)
Battery Capacity	300mAh/3.7V
Charging Time	2 hours (from 0-100%)

FCC INFORMATION

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user’s authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2AMPL-EHE-PU25

Made in China