Counsel 5000mAh Mini Power Bank Instruction Manual
EPB-CN20

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL

In the Box
- EPB-CN20 Counsel 5000mAh Mini Power Bank (x1)
- Power Cable (x1)
- User Manual (x1)

Safety Precautions
- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.

- Do no use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Product

① USB-A Output
② LED Indicator
③ USB-C Input
④ On/Off Button

Instructions
Charge the power bank fully before usage.

Charging the Power Bank
- Using the included cable, connect the USB-C connector to the power bank and the other end to a certified USB AC adapter, or USB port of a computer.

- The LED indicator will flash while power is in charging and stay solid when the power bank is fully charged.

Charging Mobile Phones & Other Electronic Devices
- Using the cable of the device you wish to charge, connect the charging cable to your mobile phone/device with the appropriate connector and the USB-A end to the USB-A output of the power bank.
- The LED indicator will illuminate when charging.
- Remove the USB cable from your mobile phone/device when it is fully charged.

LED Indicators
- Press On/Off button once to view the remaining power capacity.
- Press On/Off button twice to turn off LED.

Tech Specifications
- Battery: 5000mAh/3.7V 18.5Wh
- USB-A output: 5V/2A total (max)
- USB-C input: 5V/2A (max)

FCC Information
This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limitsare designed to provide reasonable protectionagainst harmful interference in a residentialinstallation. This equipment generates, uses and canradiate radio frequency energy and, if not installedand used in accordance with the instructions, may cause harmful interference to radiocommunications. However, there is no guarantee that interference will not occur in a particularinstallation. If this equipment does cause harmfulinterference to radio or television reception, whichcan be determined by turning the equipment off andon, the user is encouraged to try to correct theinterference by one or more of the followingmeasures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FC

Made in China