


# NAYAD®

## Care and Use Instructions

### ⚠ CAUTION


- To heat food in a microwave oven: The heat up time should not exceed 3 minutes.
- DO NOT clean with bleach, chlorine, or other harsh cleaners.
- DO NOT use it when damaged.
- Make sure to align the cover with the slots when closing it to avoid installing it the wrong way.

### USAGE RECOMMENDATIONS




### CLEANING INSTRUCTIONS


- Clean before the first use and clean the slow feeder thoroughly after use.
- Handwash with warm water and mild detergent only.
- Rinse immediately after each use with warm water.



- Rinse out the Lid with lukewarm water.



- Fill the lunch box with lukewarm water and clean the inside of the lunch box thoroughly.



- Dry the lunch box and lid separately on a drying rack.



DISHWASHER & MICROWAVE SAFE ONLY  
FOR REHEATING, NOT FOR COOKING  
REHEATING TIME NOT MORE THAN 3 MINS

US. See [nayad.com](http://nayad.com) for details.

©2021 OZEAN INTERNATIONAL INC. All Rights Reserved.  
Should you have any questions about your purchase, please  
contact us at [nayad.com](http://nayad.com).