

## ▲ CAUTION

- · Not designed for hot liquid. Use it only with cold liquid.
- · Prior to drinking, make sure the lid properly threaded to the body and screwed on completely.
- · Avoid dropping or hitting the handle. Avoid any damages of the handle to prevent leakage.
- · DO NOT use it when damaged.
- · DO NOT overfill. Fill liquids to just below the threading in the body.
- · DO NOT use cleaning agent contains bleach, chlorine, or abrasive chemicals.
- · Not for use with carbonated or pulpy beverages.
- · Keep product away from extreme heat or fire.

## **USAGE INSTRUCTIONS**



Unlock the lid by toggling the switch to the left



TO CLOSE

- · The handle also works as the switch of the spout.
- · Silicone part of the spout is not detachable.
- Avoid dropping or hitting the handle when the bottle is full to prevent damage of the handle to prevent leakage.

## **CLEANING INSTRUCTIONS**

- · Wash thoroughly before first use.
- · Rinse spout lid with warm water after each use.



Press the handle down TO OPEN




Lock the lid by toggling the switch to the right

· Dry the bottle and lid separately on a drying rack.

ល



· Handwash only.





©2021 OZEAN INTERNATIONAL INC. All Rights Reserved. Should you have any questions about your purchase, please contact us at nayad.com.