
Soft Touch Widescreen Kitchen Timer/Clock WKA-KT16



7. Silicone Case

11. Battery Cover

8. Stand

9. Magnet

Feature

- 1 Display
- MODE Button
- 3. Hour Set Button
- 4. Minute Set Button
- 5. Second Set Button 6. Start / Stop / Set Button
- (Clock & Alarm)

Battery Installation

- Open battery door from the back-side of the unit.
 Insert AAA/LR03 size battery into the battery compartment, observing correct +/- polarities.
- 3. Place battery door back onto the battery compartment.

Setting the Clock

- 1. Press the **MODE** button as many times as necessary until the clock time is shown
- 2. Press and hold the **START/STOP** button until the digits start flashing. 3. Press \mathbf{HOUR} / \mathbf{MIN} / \mathbf{SEC} buttons as many times as
- necessary until the desired clock time is shown on the LCD display
- 4. Press **START/STOP** button or leave unit idle for 30 seconds to exit setting mode.

12 HOURS / 24 HOURS Clock Format


Under clock mode, toggle select 12Hr or 24Hr format by pressing **START / STOP** button.

For the 12Hr format, the PM icon will appear on the LCD display when the clock time reaches noon.

Countdown Timer

- 1. Enter the TIMER mode by pressing the MODE button as many times as necessary until the timer icon " appears on the LCD display.
- Press **HOUR** button to set the desired hours.
- 3. Press **MIN** button to set the desired minutes. 4. Press **SEC** button to set the desired seconds
- 5. Press START/STOP button to Start or Stop the countdown timer.

When the timer is activated, the words 'HOUR', 'MIN" and 'SEC' will start flashing on the display.





- 6. The alarm will beep for 1 minute when the countdown time is reached
- 7. Press any button to stop the alarm sound (except MODE Note:
 - (a) Once the alarm sound is stopped, the display will revert to showing the previous countdown time set.
 - (b) The timer buzzer sound can only be stopped in
- 8. Resetting the countdown timer back to zero First press START/STOP button to stop the timer countdown. Then press and hold the $\dot{\text{MIN}}$ and SEC buttons at the same time until the display shows "00:00 00° ".

Count Up Timer

- 1. Under Timer mode, make sure the timer time is 00:00 00. 2. Press the **START/STOP** button to start the count up.
- 3. Press the START / STOP button to pause the timer. Press again to resume the timer.
- 4. The alarm will beep for 1 min when the max. time limit "23:59 59" is reached.
- 5. Press any button to stop the alarm sound (except MODE
- 6. Reset the count up timer back to zero by pressing and holding the MIN and SEC buttons at the same time until the display shows "00:00 00". Note: The timer needs to stop counting before it can be

reset back to zero.

Setting the Alarm

- 1. Press the MODE button until the display shows the word 'AL'.
- 2. Press and hold the **Start / Stop** button until the digits start
- flashing to enter alarm setting mode.

 3. Press the **Hour / Minute** buttons to set the desired alarm
- 4. Press the Start / Stop button or leave unit idle for 30 seconds to confirm and exit setting mode
- 5.Press the **Start / Stop** button to enable the daily alarm function. The icon ' (101) ' will show up on the display

Daily Alarm ON / Alarm OFF

- 1. Go to 'Alarm' mode the word 'AL' will show up on the screen display.
- 2. Press the **Start / Stop** button to enable the daily alarm function. The icon ' tien ' will show up on the display indicating the daily alarm function is activated.
- 3. To disable the daily alarm, simply press the Start / Stop button and the icon 'will disappear from the LCD

Attaching the Unit to Metal surface

The clock timer can be affixed to a metal surface such a refrigerator door. Make sure the surface area is cleaned before attaching the unit.



The clock timer can also be placed on a flat surface such as a table top by opening the plastic stand outward from the backside

Battery

AAA/LR03 x 1 piece



