

Prima 38 oz Microwaveable Stainless Steel Bowl With Vented Glass Lid

WKA-PR26

Care & Use Instructions

Please use a soft sponge for cleaning. DO NOT use cleaners with coarse particles or scrubber that will scratch the product. White vinegar or baking soda can be used, with hot water, to remove any limescale.

Please DEFROST the frozen food before heating it in the microwave.

DO NOT put the empty stainless steel container into the microwave to heat up. When warming in the microwave, please open the vent of the lid and heat only ONE container at a time.

The heating range, for 1000W microwave, is max 5 minutes.

For more even heating, please place container in center of microwave plate.

The SS container will be hot, so care is needed when handling it.

DO NOT use this product to make popcorn or melt sugar in the microwave.

The SS body can be safely used in the freezer with minimum - 40°F (- 40°C), the lids with minimum 14°F (- 10°C).

The SS body can be safely used in conventional oven with maximum 482°F (250°C). DO NOT use lid in conventional oven.

DO NOT heat this item using direct heat of stove top or grill.

Avoid touching logo when it is hot. Imprint may feel tacky immediately after microwaving or when it is hot. Please allow adequate cooling time before touching logo or container.