Instructions

- Rotate handles upward, then pull up to open lantern.
  LED light automatically turns on when opened.

- Unscrew bottom compartment to replace batteries.

- Press button on side to operate fan.