



- Lift the magnetic surface from the bottom base.
- Adjust the magnetic surface to appropriate angle.
- Put the bottom base on a smooth surface and press tightly.
- Slide the knob to the left from OFF to ON.
- The bottom base is steadily fastened on the surface.
- Attach MagSafe device or phone case to the magnetic surface.

***FOLDED***



***UNFOLDED***