

## **Brass No-Touch Protection Tool**

Avoid touching contaminated surfaces with this tool. Insert your finger into the end with the hole.







Use extended claw to open door and drawer handles.

Use tip to press elevator and other buttons.