

# **SWIRL PORTABLE BATTERY-OPERATED FAN INSTRUCTION MANUAL WTV-SW26**

**READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.**


## **IN THE BOX**

- WTV-SW26 Swirl Portable Battery-Operated Fan (x1)

## **SAFETY PRECAUTIONS**

- This device is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.  
Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device could fall into liquid.
- Do not expose this product to rain, water or excessive humidity.
- Do not handle the device or battery with wet hands.
- This product contains small parts and is NOT suitable for children.
- Do not use the product if it has been damaged in any way.
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children.

## PRODUCT DIAGRAMS



## INSTRUCTIONS

- Pinch the clip of battery compartment cover to open the battery compartment on the back of the fan.
- Insert 2x AA batteries (included) according to the polarity markings (+/-).
- Remove the battery isolator before use, if applicable.
- Close the battery compartment securely before use.

### Note:

- Insert batteries with the correct polarity (+/-).
- Do not mix battery types, or mix old and new batteries.
- Only use 2x AA batteries.
- Remove batteries if the fan will not be used for an extended period.
- Keep batteries away from children. Do not ingest battery. If

ingested or placed inside body, seek medical attention immediately. Ingesting can cause severe chemical burns in just t two hours and result in serious injury or death.

- If the battery compartment does not close securely, stop using the device and keep away from children.
- Dispose of used battery according to your local environmental laws and guidelines.

## **USING THE FAN**

- Slide the **[Power] switch upward** to turn the fan ON.
- Slide the **[Power] switch downward** to turn the fan OFF.
- Turn the fan OFF when it's not in use.

## **FCC INFORMATION**

This device complies with Part 15 of the FCC Rules.

**Caution:** Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Made in China