Allegro TWS Earbuds & Solar Powered Charging Case



Instruction Manual EHE-AT21

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL.

In the Box

- EHE-AT21 Allegro TWS Earbuds with Solar Powered Charging Case (x1)
- Power Cable (x1)
- User Manual (x1)


Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- Never use the device for anything other than its intended purpose.
- ONLY use the supplied power cable.
- Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Product

FRONT BACK





Instructions

Note: Remove plastic isolator from each earbud before use and dispose properly.

Be sure to fully charge the earbuds and charging case before using for the first time.

Charge the Earbuds

- \bullet Make sure the earbuds are securely placed into the charging case.
- Place the right and left earbuds into the corresponding slots so that the magnetic metal charging contacts line-up correctly.
- The earbud LED indicator will glow **RED** and the charging case LED indicator will glow **BLUE** when the earbuds are charging.

 Once the earbuds are fully charged, the earbud LED indicator and the charging case LED indicator will turn off.

• You will hear a beep prompt when the earbuds need recharging.

Charge the Charging Case

- Plug the small connector of the included charging cable into the USB-C charging port on the charging case.
- Plug the large connector into a USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
- \bullet The charging case LED indicator will flash $\bf RED$ when charging and turn solid $\bf RED$ when fully charged.

Charge the Charging Case with Solar Panel

- Place the charging case in bright and consistent sunlight.
- The case will begin to charge instantly when the solar panel is exposed to sunlight.

Pair & Connect with a New Device

- The earbuds will turn on and enter pairing mode automatically once they are removed from the charging case. The earbud LED indicator will blink alternately RED and BLUE indicating that the earbuds are in pairing mode.
- Open the Bluetooth menu on your smart devices and search for new devices.
- When you see "Allegro TWS Earbuds" listed, tap it to connect.
- Once connected with your device, there will be a beep.
- Previously connected earbuds will connect automatically after they are powered on.
- The earbuds can be used as a single or a pair.
- The earbuds will power off automatically if you do not connect to the

earbuds in 5 minutes or the earbuds are securely placed into the charging case.

Touch and Button Functions

- Touch the multi-function button on either side of the earbuds to answer an incoming call, and again to end the call.
- Touch and hold the multi-function button on either side of the earbuds to reject an incoming call.
- When playing music:
- Touch the multi-function button on either side of the earbuds to pause/resume music.
- Touch twice on the multi-function button on the left earbud to play the previous track.
- Touch twice on the multi-function button on the right earbud to play the next track.
- Touch and hold the multi-function button on either side for 2 seconds to activate the voice assistance of your device, Siri (iOS devices) or Google Voice Assistant (Android devices). You will hear a beep prompt to indicate that your voice assistant is activated.

Tech Specifications	
Rate Power	5mW
Driver Size	13 mm
Frequency Response	20Hz ~ 20KHz
Connection Range	33 feet
Continuous Play Time	Up to 4 hours (with max volume)
Battery Capacity of Earbuds	35mAh/3.7V *2 (0.1259 Wh)
Battery Capacity of Charging	400mAh/3.7V (1.48 Wh)
Case	
Earbuds Charging Time	Approx. 55 minutes
Charging Case Charing Time	Approx. 80 minutes

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \bullet Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

