

ASCENT RECHARGEABLE WIRELESS MOUSE

INSTRUCTION MANUAL

EMO-AS25

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.

WHAT'S INCLUDED:

- 1x EMO-AS25 Ascent Rechargeable Wireless Mouse
- 1x Charging Cable

SAFETY PRECAUTIONS

- This device is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or charging cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or charging cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or charging cable is damaged. If device or charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

INSTRUCTIONS

Be sure to fully charge the mouse before using for the first time.

CHARGE THE MOUSE

- Plug the small connector of the included charging cable into the USB-C charging port on the mouse.
- Plug the large connector into a USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
- The LED indicator around the scrolling button will **illuminate RED** when charging and turn OFF when fully charged.

INSTALLING THE USB NANO RECEIVER

- Slide open the battery compartment cover underneath the mouse. Take out the USB Nano Receiver and slide back the battery compartment cover.
- Plug the USB Nano Receiver into the USB port of a laptop or PC.
- Make sure the mouse has been fully charged and is switched on.
- The laptop or PC will identify the receiver automatically and wireless mouse will begin installation instructions.
- The mouse will be ready for users when the installation is complete.

PAIR & CONNECT WITH A NEW DEVICE

- If you do not want to use the USB Nano Receiver, you can connect the mouse with your laptop or PC by Bluetooth.
- Switch on the mouse. The LED indicator around the scrolling button will **flash BLUE** indicating the mouse is in pairing mode.
- Open the Bluetooth menu on your laptop or PC and search for new devices.
- When you see “**Ascent Mouse**” listed, click it to connect. The LED indicator will turn OFF when paired successfully.
- Previously paired mouse will pair automatically after they are powered on.

USING THE WIRELESS OPTICAL MOUSE

- Press the DPI button to switch speed between 800 DPI, 1200 DPI and 1600 DPI.
- The mouse will enter sleeping mode automatically if inactive for 10 minutes and will reactive once any key is pressed.
- Optical mouse could have operating issues on glass, black, and reflective surfaces.
** For the best operation, please use a mouse pad.*
- If using on a desktop PC, the distance from workspace to computer could cause connection issues to the receiver. Suggestion would be to use an extended USB cable.

TECH SPECIFICATIONS

- | | |
|---|---|
| • Sensor: Optical | • Battery Capacity: 400mAh |
| • DPI Level: 800-1200-1600 | • Input: DC 5V/300mA |
| • Connection: Wireless 2.4GHz (RF), Bluetooth | • Charging Time: 2 hours |
| • Frequency Range: 2402~2480 MHz | • Continuous Using Time: 50 hours |
| | • Works on: Windows XP & Mac OS 8 and above |

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2AH9Y-W2416

Made in China