

**VANGUARD 10000MAH 20W PD POWER BANK
WITH CHARGING CABLE LANYARD
INSTRUCTION MANUAL
EPB-VA26**

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE.

IN THE BOX


- EPB-VA26 Vanguard 10000mAh 20W PD Power Bank (x1)

WARNING

When using this product, basic precautions should always be followed, including the following:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, close supervision is necessary when the product is used near children.
- c) Do not put fingers or hands into the product.
- d) Do not expose power bank to rain or snow.
- e) Use of a power supply or charger not recommended or sold by power pack manufacturer may result in a risk of fire or injury to persons.
- f) Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- g) Do not use the power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- h) Do not disassemble the power bank. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- i) Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100°C may cause explosion. The temperature of 100°C can be replaced by the temperature of 212°F.
- j) Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained
- k) Switch off the power bank when not in use.

PRODUCT DIAGRAMS



INSTRUCTIONS

Charge the power bank fully before using for the first time.

CHARGING THE POWER BANK

- Plug the USB-C tip of your charging cable (not included) into the USB-C port on the power bank. Plug the other end of the cable into a USB power source, such as the USB port on a computer or into a certified USB adapter (not included), and plug into a wall socket.
- Or using the built-in USB-C cable of the power bank, connect the built-in USB-C cable to a USB power source, such as the USB port on a computer or into a certified USB adapter (not included), and plug into a wall socket.
- The digital display will display power level while power bank is in charging.
Note: *When the power bank is being charged with 18W or above power adapter, the fast-charging icon will appear in LED display.*

CHARGING ELECTRONIC DEVICES WITH THE POWER BANK

- Using the built-in cables of the power bank, connect the built-in charging cable to your device with the appropriate connector.
- The power bank will begin to charge automatically.
- The digital display will show available power level of battery when charging.
- Remove the cable from the charged device when it is fully charged.
Note: *When the power bank is being charged with 18W or above power adapter, the fast-charging icon will appear in LED display.*

TECH SPECIFICATIONS

- Battery/Cell Capacity: 38.5Wh, 10000mAh/3.85V
- USB-C Port & Cable Input: DC 5V/3A, 9V/2A, 12V/1.5A (18W Max.)
- USB-C Port & Cable Output: DC 5V/3A, 9V/2.22A, 12V/1.67A (20W Max.)
- Lightning Cable Output: DC 5V/2.4A
- Working Temperature: 14°F ~ 113°F (-10°C ~ 45°C)

FCC INFORMATION

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Made in China