Cobalt Light-Up Wireless Speaker Instruction Manual ESP-CB22


READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL


- ESP-CB22 Cobalt Light-Up Wireless Speaker (x1)
- Charging Cable (x1)
- Instruction Manual (x1)

Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- · Never use the device for anything other than its intended purpose.
- ONLY use the supplied power cable.
- Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions
- · Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- \bullet Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- · Low battery may cause dysfunction
- · Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Product





Be sure to fully charge the speaker before using for the first time.

Charge the Speaker

- Lift the protective rubber seal of the charging port, and plug the small connector of the included charging cable into the USB Type-C charging port on the speaker.
- Plug the large connector into a USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
- The LED light on the top of the speaker will glow **RED** when charging and turn **OFF** when fully charged. Make sure the protective rubber seal is completely sealed when charging is complete.

• On lower power, a tone will be heard indicating that the speaker needs to

Pair & Connect with a New Device

- Press and hold the [O] button for 3 seconds to power ON. A tone will be heard and the LED light will flash SIX COLORS indicating that the speaker is in pairing mode.
- Open the Bluetooth menu on your smartphone and search for nev devices.
- When you see "Cobalt Outdoor Speaker" listed, tap it to connect. LED light will fade in **SIX COLORS** when paired successfully.
- · Previously connected speaker will connect automatically after they are
- Press and hold the [O] button again for 3 seconds to power OFF.

TWS Pairing Two Speakers

If you have two Cobalt Light-Up Wireless Speaker, you can make a True Wireless (TWS) pairing between them by following below steps:

- Place the two speakers near each other, and power ON both speakers at the same time.
- The speaker should pair to each other automatically. The LED lights on both speakers will flash in SIX COLORS.
- Follow the instructions under "Pair & Connect with a New Device" to connect your device to the speaker pair.

- Triple press the [O] button on either speaker to disconnect two speakers when the speakers are not paired to your device.
- If you have previously paired your device to one of the speakers, you may need to turn off Bluetooth of your device while you pair the speakers to each other.

Using the LED Lights

Press the [+] ${\bf button}$ and [-] ${\bf button}$ at the same time to switch LED light modes.

Music Sync Mode

- The LED light will flash to the beats of music when playing music. Color Changing Mode
- Press the [+] button and [-] button at the same time, the LED light will turn to color changing mode. The LED light will keep color changing of SIX COLORS.

Light Off Mode

• Press the [+] button and [-] button at the same time again, the LED light will turn OFF

Using the Speaker in Wet Conditions

The speaker has an Ingress Protection rating of $\ensuremath{\text{IPX6}}.$ This means it is protected against water spray and splashes from all directions. It is NOT protected from submersion in water, such as flooding.

Always make sure that the protective rubber seal is completely covering the charging port before using the speaker in wet conditions. Never charge the $\,$ speaker in wet conditions.

Play & Calling

- Press the [O] button to play/pause your audio.
- Press the [+] button to skip to next track;
- Press and hold the the [+] button to increase volume. • Press the [-] button to skip to previous track;
- Press and hold the [] button to decrease volume
- When there is an incoming phone call, press the [O] button once to answer an incoming phone call, and again to end a phone call.
- Press and hold the [O] button to reject an incoming call.
- Press twice on the [O] button to redial the last dialed number.

• If you have trouble pairing your earbuds, forget the pairing name "Cobalt Outdoor Speaker" from the list of the connected device and turn off the Bluetooth

• Follow the instructions under "Pair & Connect with a New Device" to pair with the speaker again

iech specifications		
	Speaker Output	5W
	Impedance	4 ohm
	Frequency Response	20Hz ~ 20KHz
	S/N Ratio	>80dB
	Connection Range	33 feet
	Continuous Play Time	Up to 4 hours (with max volume)
	Battery Capacity	1200mAh
	Charging Time	2 hours (from 0-100%)
	Waterproof Grade	IPX 6

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



