


READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL.

In the Box

- Rave Light-Up Wireless Speaker (x1)
- Charging Cable (x1)
- Instruction Manual (x1)

Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or charging cable is damaged. If device or charging cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Product

Instructions

Be sure to fully charge the speaker before using for the first time.

Charge the Speaker

- Plug the small connector of the included charging cable into the USB Type-C charging port on the back of the speaker.
- Plug the other end of the cable into a USB power source, such as the USB port on a computer or into a certified USB adapter (not included), and plug into a wall socket.
- The charging LED indicator on the back will glow **RED** when charging and turn off when fully charged.

- On lower power, you will hear a voice prompt saying "Battery low," indicating that the speaker needs to be recharged.

Pair & Connect with a New Device

- **Press and hold the Multi-Function button** for 3 seconds to power ON. You will hear a voice prompt saying "Ready, waiting for connection." The speaker LED indicator will flash **BLUE** indicating the speaker is in pairing mode.
- Open the Bluetooth menu on your smart device and search for new devices.
- When you see "**Rave Speaker**" listed, tap it to connect. You will hear a voice prompt saying "Connected." and the speaker LED indicator will turn solid **BLUE** when paired successfully.
- Previously paired speaker will pair automatically after they are powered on.
- Press and hold the **Multi-Function button** again for 3 seconds to turn off the speaker.
- **Note:** *The speaker will automatically shut off after 5 minutes when it is disconnected.*

Play & Calling

- Press the **Multi-Function button** to play/pause your audio.
- Press the **▷ button** to skip to next track;
- Press the **◁ button** to skip to previous track;
- When there is an incoming phone call, press the **Multi-Function button** once to answer an incoming phone call, and again to end a phone call.
- *Press and hold* the **Multi-Function button** to reject an incoming call.
- Volume can be adjusted with the **Volume Dial** on the front of the speaker or with the controls on your paired device.

Reset the Speaker

- If you have trouble pairing your speaker, forget the pairing name “**Rave Speaker**” from the list of the connected device and turn off the Bluetooth.

- Follow the instructions under “**Pair & Connect with a New Device**” to pair with the speaker again.

Using the LED Lights

- Press the **Light button** on top of the speaker to flip through different LED light modes, including turning the lights ON and OFF.

Tech Specifications

Speaker Output	5W
Impedance	4 ohm
Frequency Response	20Hz - 20KHz
S/N Ratio	>80dB
Connection Range	33 feet
Battery Capacity	1200mAh/3.7V 4.44Wh
Power Input	DC 5V/800mA
Working Temperature	32°F - 122°F (0°C - 50°C)

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

