

**Daybreak Digital Alarm Clock
Instruction Manual
WHO-DB22**


READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL.

In the Box

- WHO-DB22 Daybreak Digital Alarm Clock (x1)
- Power Cable (x1)
- Instruction Manual (x1)

Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the power cable when not in use. Do not pull the power cable to disconnect, or use the cable as a handle.
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.



Connecting to Power

- Plug the small connector of the included power cable into the USB Type-C port on the clock.
- Plug the other end of the cable into a USB power source, such as a certified USB adapter (not included), and plug into a wall socket.
- The clock display will turn on when the clock is connected to power.

- If the clock is disconnected from power, it will only save the time and settings for 60 seconds.

Display Modes

- Press the **[UP]** button on the back of the clock to switch between clock display modes. The display must be showing the clock time in order to switch the mode. Press the **[SET]** button to save as the default mode.
- In **Mode 1 (dP-1)**, the display will show the time for 10 seconds and then flash the date and temperature for 2 seconds.
- In **Mode 2 (dP-2)**, the display will stay showing the selected information (clock time, alarm time, date or temperature) at all times. Press the **[SET]** button to change the information selection.

Setting the Time

- Make sure the clock time is shown on the display. You may need to press the **[SET]** button until the time is displayed.
- Press the **[DOWN]** button to toggle between the 12-hour and 24-hour clock.
- *Press and hold* the **[SET]** button to set the time. The time hours will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust. The dot in the upper left corner of the display will appear when the hour is PM. Press the **[SET]** button to save the hour setting.



Setting the Alarm Time

- Press the **[ALARM]** button to turn the alarm ON or OFF. The dot in the left of the clock display will light up when the alarm is turned on.



- Press the **[SET]** button until the alarm time is displayed.
- *Press and hold* the **[SET]** button to set the alarm time. The alarm hours will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust. The dot in the upper left corner of the display will appear when the hour is PM. Press the **[SET]** button to save the alarm hour setting.
- The alarm minute digits will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust, and press the **[SET]** button to save. The clock will return to default display mode.

Setting the Date

- Press the **[SET]** button until the date is displayed.
- *Press and hold* the **[SET]** button to set the date. The year will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust. Press the **[SET]** button to save year setting.
- The month will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust, and press the **[SET]** button to save month setting.
- The day will begin flashing. Press the **[UP]** and **[DOWN]** buttons to adjust, and press the **[SET]** button to save. The clock will return to default display mode.

Changing Temperature Units

- Press the **[SET]** button until the temperature is displayed.
- Press the **[DOWN]** button to switch between degrees Fahrenheit (°F) and Celsius (°C).
- Press the **[SET]** button to save. The clock will return to its default display mode.

- ### Using the Beside Light

- Press the [SNOOZE/LIGHT] button on the top of the clock to turn the bedside light ON in white light mode.
- Press the [SNOOZE/LIGHT] button to adjust the light brightness between low, medium and high.
- Press and hold the [SNOOZE/LIGHT] button to switch to color-changing light mode.
- In color-changing light mode, press the [SNOOZE/LIGHT] button to choose a light color.
- Press and hold the [SNOOZE/LIGHT] button to switch back to white light mode.

Note:

- The bedside light can only be powered OFF from white light mode.
- The bedside light can NOT be used when the clock is in sunrise mode or snooze mode.

Using the Sunrise Light

- The clock's sunrise light function will turn on 20 minutes before your alarm time, and gradually increase in brightness until your alarm goes off.
- To use the sunrise light, set the alarm before your go to sleep.

Snooze Function

- Press the **[SNOOZE/LIGHT]** button on the top of the clock when the alarm goes off to activate the Snooze function. The alarm will ring again in 5 minutes. The sunrise light will continue to shine at full brightness during the snooze time.
- To turn the alarm and sunrise light off completely, press and hold the **[SNOOZE/LIGHT]** button when alarm goes off. This only turns them off for the day, and they will activate again as normal the next day.

Using the USB Power Output

- To power or to charge a USB device using the USB power output port on

the back of the clock, simply plug your device's USB connector into the USB output port and the other end into your device while the clock is connected to power.

Tech Specifications

- LED Quantity: 15 units
- Luminous Flux: 160 lumen
- Power of Light: 3W
- USB Type-C Input: DC 5V/2A
- USB Output: DC 5V/1A
- Working Temperature: 32°F - 122°F (0°C - 50°C)

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to

which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

